

Instructions for use

Combination lock handle 6000



Functions

1. Individually settable combination
2. Locking of the handle by changing the combination
3. Unlocking of the handle by
 - a) Turning the combination to your individual code **or**
 - b) Using the key-lock

1. Setting your individual combination

In order to set an individual combination the handle needs to be in the opened position. The original code is 0-0-0-0. use a pointed item (i.e. a pen) to push the coder (see sketch) as far as it will go and hold it in this position while turning the dials to the combination you wish to use. Then release the coder. You have now set a code that will allow opening the handle at any time.

2. Locking the handle

The handle is locked as soon as you turn the dials to a combination other than your individual code.

3. Opening the handle

- a) By turning the dials to your individual combination.
- b) By opening the cylinder lock with the key (when you are in possession of the key you can open the handle without knowing the combination)

